



PASOLINK

NETWORK

MANAGEMENT

TERMINAL

PNMT (Java version)
Operation Manual
(for PASOLINK V3)

Table of Contents

DOCUMENT WARRANTY	1
1 GETTING STARTED.....	2
1.1 INTRODUCTION	2
1.2 CONVENTIONS USED IN THIS MANUAL.....	2
1.3 PNMT COMMUNICATION INTERFACES.....	3
1.3.1 <i>Communications</i>	3
2 SYSTEM OPERATION & MAINTENANCE.....	5
2.1 THE PNMT SCREEN	5
2.2 LAUNCHING THE PNMT APPLICATION.....	7
2.3 LOGIN	8
2.3.1 <i>User Access Privilege Levels</i>	9
2.4 SHUTTING DOWN PNMT.....	10
2.5 SEARCHING FOR NETWORK ELEMENTS AND CONNECTING TO SELECTED NETWORK ELEMENT....	11
2.6 CHANGE PASSWORD.....	12
2.7 ALARM BUZZER SETTING.....	13
2.8 REFRESH.....	14
2.9 REMOTE VIEWING PNMT MAIN WINDOW	15
2.10 LICENSE.....	16
2.11 OVERALL TAB	17
2.12 ODU TAB	18
2.13 IDU TAB.....	20
2.13.1 <i>IDU Tab</i>	20
2.13.2 <i>Loop Back</i>	23
2.13.3 <i>Alarm Inhibit</i>	24
2.14 AUXILIARY I/O TAB	25
2.14.1 <i>Optocoupler Input Setting</i>	25
2.14.2 <i>Relay Output Setting</i>	26
2.15 PM CARD MONITOR	27
2.15.1 <i>PM Card Monitor</i>	27
2.15.2 <i>Setting the Date/Time</i>	27
2.15.3 <i>PM Card Reset</i>	28
2.15.4 <i>Downloading the Configuration Files to the PMC</i>	28
2.15.5 <i>Downloading a New Program File for the PMC</i>	30
2.15.6 <i>Uploading PMC Configuration File to PNMT PC</i>	31
2.16 MAINTENANCE	32

2.16.1	<i>Maintenance Menu</i>	32
2.16.2	<i>Selecting Maintenance Mode</i>	33
2.16.3	<i>Selecting TX Mute Status</i>	33
2.16.4	<i>Selecting Carrier Wave Status</i>	34
2.16.5	<i>Selecting BER AIS</i>	35
2.16.6	<i>Switchover (For 1+1 system only)</i>	35
2.16.7	<i>TX Switch (For 1+1 system only)</i>	35
2.16.8	<i>RX Switch (For 1+1 system only)</i>	36
2.17	EQUIPMENT SETUP	37
2.17.1	<i>Equipment Configuration Monitor</i>	37
2.17.2	<i>Setting the Frequency Plan</i>	38
2.17.3	<i>Setting the TX Attenuation</i>	38
2.17.4	<i>Bit Rate Setting</i>	38
2.17.5	<i>Setting the Frame ID</i>	39
2.17.6	<i>Setting the BER Threshold</i>	39
2.17.7	<i>Setting the AIS SEND</i>	40
2.17.8	<i>Setting the AIS RCVD</i>	40
2.17.9	<i>Setting the Service Channels (SC4/SC5)</i>	40
2.17.10	<i>Editing the NE Name</i>	40
2.17.11	<i>Editing the Note for NE</i>	41
2.18	LINK PERFORMANCE MONITOR	42
2.18.1	<i>Viewing Summary Link Performance Monitor</i>	42
2.18.2	<i>Threshold Setting</i>	45
2.18.3	<i>Link Performance Monitor (Daily Data) window</i>	46
2.18.4	<i>Link Performance Monitor (15-min Data) window</i>	47
2.18.5	<i>All Data Reset</i>	47
2.19	NE STORED LOG	48
2.19.1	<i>NE Stored Log Monitor</i>	48
2.20	VERSION TAB	49
2.20.1	<i>Version Monitor</i>	49
2.21	LICENSE IMPORT	50
2.21.1	<i>License import</i>	50

Document Warranty

1. The information contained in this document is subject to change without prior notice.
2. The PNMS/PNMT screenshots in this manual are only examples. Screens will vary according to equipment configurations, equipment operation modes, setting parameters, PNMS/PNMT application program version, etc. Screens contained in this manual are current at the moment of publication, and they may differ slightly from the actual screens on your PNMS/PNMT.
3. To use this manual, you need a sound understanding of the restrictions, limitations and precautions involved in operating the equipment properly. Always refer to the equipment manual to ensure proper operation of the equipment.

1 Getting Started

1.1 Introduction

The Pasolink Network Management Terminal (PNMT) was developed by NEC to manage its Pasolink and Pasolink+ fixed point-to-point wireless access system networks. The PNMT is a scaled down version of the Pasolink Network Management System (PNMS) that is designed as a maintenance tool for field engineers to locally and remotely monitor alarms, control points, generate reports, and archive data, all within a familiar graphical user interface, and all in real time. The PNMT is a Mobile laptop computer fitted with the NEC PNMT software package that interfaces and controls NEC PASOLINK series short haul wireless communications radio equipment.

This software package remote monitors and controls the status and configuration of an entire PASOLINK network with associated equipment including the performance of the actual microwave links.

1.2 Conventions Used in this Manual

Font	What the Font Represents	Example
<i>Italics</i>	For manual titles or related document names.	Please refer to <i>Pasolink Operation Manual</i> for details.
Hostname Bold (or bold italics)	Items (phrases) in the user interface. Items (phrases) in the computer display. File and directory <i>names</i> .	The Overall window ... XXXXXXXXXXXXXX
[Button]	Buttons on the user interface.	Click [OK] to continue ... Click [Execute] to send command.
Menu Items	A menu name followed by a colon (:) means that you must select the menu and then a menu item. When the menu item is followed by an arrow (→), a cascading menu is displayed.	Select System → Login/Logout
<username>	A command variable where for which the user must enter the appropriate value. This is also commonly used when asking for a password.	<password>
Keycap	Keyboard keys.	Press Enter key.

1.3 PNMT Communication Interfaces


1.3.1 Communications

Communications between the PNMT and the wireless communications network equipment are possible

- via the LA Port of the Pasolink equipment,
- via the **DSC** to a remote node in the network.

a) LA Port Interface

The LA Port is on the front of the Pasolink unit.(as illustrated below).




Exterior of Pasolink Front Panel

The LA Port consists of a DB15 connector that plugs into the PM installed in the IDU via a serial cable which connects to the relevant communications port of the PNMT Computer.

The LA Port has the following properties:

- Port Configuration: RS-232
- Connector type: Subminiature DB15 (female)
- Bit per second rate: 1200/2400/4800/9600/19200 (default 19200)
- Stop bits: 1
- Data bit length: 8
- Parity: None

The following table shows the cabling pin allocation for the connection between LA Port and the PNMT PC.



Cabling Diagram for PNMT to LA Port connections

NOTE

When the cable between PNMT and NE is unplugged, communication will be disrupted and a message prompting reconnection will appear a few minutes later on the PNMT screen. Please wait for the message to appear before changing/reinserting the cable connection for the NE.

2 System Operation & Maintenance

This chapter explains the menu structure and procedures for operating the PNMT. The explanation uses typical PNMT screenshots to illustrate the menu hierarchy.

2.1 The PNMT Screen

The PNMT window is composed of the following main areas parts (Refer to Figure 1).

- **Title bar**
The title bar of a window is used to indicate the title of the window.
- **Common Menu bar**
The common menu bar of the window presents the **System** and **Help** options, illustrates which commands can be executed from among the various options. The Help function can also display a pdf version of this operation manual.
- **NE-specific Menu bar**
This menu is a list of tasks that can be performed on a specific network element (NE) displayed in the PNMT. Configuration, Event Log, and Link Performance Monitor functions can be executed with the NE-specific Menu bar.
- **Block Diagram**
The block diagram shows the equipment comprising the Pasolink wireless communication system. Its main purpose in the window is to display the current summary of the alarm stateuses of the equipment. You can click on a specific block to display the status of equipment in the data window.
- **Data window**
This window displays in detail the status and alarm items for specific equipment of the NE. You can select the tab or the block of a specific part that you wish to monitor in the data window.
- **Tabs**
To view the status and alarms in the Pasolink rwireless system, click on the tab at the bottom of the Data window.
- **Command Button**
The command button is used to enter (on the computer) the data specified in the pop-up window.
- **Selectable Field**
The selectable field is a standard Windows input field where the user can scroll down a list of values available for that option.
- **Login User**
This indicates the user who is currently logged in to the PNMT.
- **One Touch Expandable Button / Divider**
Initially the PNMT screen is split evenly to display the data from the two NE's within a hop by using a divider. Click this button to move the divider to the edge of the window




Figure 1 Standard Components of PNMT window

2.2 Launching the PNMT Application


To start PNMT:

1. Turn system power ON.

NOTE

Connect the PNMT cable 30 seconds after IDU's power has been turned ON and make sure that the PNMT cable is connected between Com 1 port of the PNMT PC and the PNMT port of the IDU.

2. Login to Windows.
3. Click **Start → Programs → PNMTj → Pnmt**, then continue to the login window.



NOTE

Please do not change the clock settings of your personal computer once PNMT has started.

2.3 Login


Users are registered by means of login name and password.

To protect the network and the network management system from unauthorized access or modifications, five levels of users are different access privileges are defined (refer to the table shown in section 2.3.1 **User Access Privilege Levels**. The functions that are available depend on the individual user's access level..

The highest or administrator level has full access to the network and the management system.

To login:

1. Start PNMT and the Login window appears.



Login window

2. Enter the <User name>.
3. Enter the valid <Password> for the specific user.
4. Click [**Login**].

If you wish to exit the program, click [**Exit**].

2.3.1 User Access Privilege Levels

✓: Available, -: Not Available

Functions		User Name and Accessible Functions				
Category	ITEM	Monitor	User	Local	Remote	Admin
Menu-System	Change Password	✓	✓	✓	✓	✓
	Alarm Buzzer	-	✓	✓	✓	✓
	Connect (Remote Login)	-	-	-	✓	✓
	Exit	✓	✓	✓	✓	✓
Menu-Refresh	Refresh	✓	✓	✓	✓	✓
Menu-Help	Help	✓	✓	✓	✓	✓
	About	✓	✓	✓	✓	✓
	License	✓	✓	✓	✓	✓
IDU	WS Alarm Inhibit (WS option)	-	✓	✓	✓	✓
	CH (LB1)	-	-	✓	✓	✓
	CH (LB2)	-	-	✓	✓	✓
	CH (Alarm Inhibit)	-	✓	✓	✓	✓
MAINT	MAINT	-	✓	✓	✓	✓
	TX Mute	-	-	✓	✓	✓
	CW	-	-	✓	✓	✓
	BER AIS	-	✓	✓	✓	✓
	Switch over (1+1)	-	-	✓	✓	✓
	TX Switch (1+1)	-	-	✓	✓	✓
	RX Switch (1+1)	-	-	✓	✓	✓
Equipment Setup	Frequency Plan (CH)	-	-	✓	✓	✓
	TX Attenuation	-	-	✓	✓	✓
	BIT Rate (Bit Rate Free Type)	-	-	-	-	✓
	Frame ID	-	-	✓	✓	✓
	BER Threshold	-	✓	✓	✓	✓
	AIS RCVD	-	✓	✓	✓	✓
	AIS SEND	-	✓	✓	✓	✓
	SC4	-	✓	✓	✓	✓
	SC5	-	✓	✓	✓	✓
	NE Name	-	-	✓	✓	✓
Aux I/O	Note	-	✓	✓	✓	✓
	Input Name	-	✓	✓	✓	✓
	Input Condition	-	✓	✓	✓	✓
	Input Status Strings	-	✓	✓	✓	✓
	Output Name	-	✓	✓	✓	✓
PMON	Output Control	-	✓	✓	✓	✓
	PMON Threshold	-	✓	✓	✓	✓
	PMON All Data Reset	-	-	✓	✓	✓
Logging	Save to disk	-	✓	✓	✓	✓
	Save to disk	-	✓	✓	✓	✓
PMC	Date/Time	-	-	✓	✓	✓
	PMC Reset	-	-	✓	✓	✓
	Download Configuration File	-	-	-	-	✓
	Update	-	-	-	-	✓
	Download PMC Program File	-	-	-	-	✓
	Upload Configuration File	-	-	-	-	✓

*Admin : Enabled to access all Network Elements.

*Remote : Enabled to access all Network Elements.

(Disabled from changing network configuration or changing/downloading programs)

*Local : Enabled to access Local and Opposite NE.

(Disabled from changing network configuration and changing/downloading programs)


*User : Enabled to access items insofar as equipment is not affected.

*Monitor : Enabled to monitor only and disabled from control functions.


2.4 Shutting Down PNMT

To exit the PNMT application:

1. Click **System → Exit** on the menu bar of the main window



2. Click **[OK]** to confirm that you wish to exit the application.




2.5 Searching for Network Elements and Connecting to Selected Network Element

The summary description of the current network element (Network Element Name, Equipment Type, Opposite Network Element, etc.), where PNMT is connected, is displayed with this function. Summary description of the opposite network element for that link is also displayed.

To search for, or connect to, a network element in the network:

1. Click **System → Connect...** on menu bar of PNMT main window.



NOTE

Initially only the current NE physically connected to the PNMT and its opposite NE counterpart will be shown on the Network Element List.


2. Click  icon in the tool bar or **List → Search for Network Element** in the menu bar on the Network Element List window to display all connectable Network Elements in the network.
3. Select and highlight the network element to be viewed.
4. Click  icon in the tool bar or **List → Connect to Network Element** in the menu bar on the Network Element List window. The PNMT main window of the selected network element and its opposite NE counterpart will be displayed.



2.6 Change Password

To change the password:

1. Click **System → Change Password** on the menu bar on main window.



2. Enter the **Old password**.
3. Enter **New Password**
4. Enter new password in the **Confirm New Password** field to confirm.
5. Click **[OK]**.

NOTE


For details on initial user name and password, please refer to PNMT Installation manual.

2.7 Alarm Buzzer Setting

This function is used to activate and set the Alarm Buzzer. The desired sound scheme can also be set using this function.

To set the Alarm Buzzer:

1. Click **System → Alarm Buzzer** in the main window.



2. Select the **Wave file** box to activate the buzzer. **No sound** is the initial factory setting of the PNMT.
3. Enter the location of the sound file (*.wav) Otherwise; click [...] to locate the desired file. You can also preview the *.wav file by clicking on the arrow next to the browse button.
4. Click **[OK]** or **[Apply]** to activate the new setting.

NOTE


When the text column is a blank, it is possible to set it. In this case, the buzzer sound does not ring even though the buzzer stop function is disabled.

2.8 Refresh

This function is supported only by PNMT. This function enables PNMT to acquire all status data manually and to update equipment information

To Refresh:

1. Click Refresh → Refresh in the main window or click on the refresh icon in the tool bar.




NOTE

Metered items such as TX power, RX level, power supply and BER are automatically refreshed every 15 seconds. This function is used when the immediate refreshing of these metered items is necessary or when immediate confirmation of all current status information is required.

2.9 Remote Viewing PNMT main window

You can view a target link within one CPMC cluster of the Pasolink network by searching through the connected NE's and then connecting to a target NE. Please refer to **Section 2.5 Searching for Network Elements and Connecting to Selected Network Elements**. This function allows remote connection to any NE in the network.

NOTE: For multi-CPMC network, you can only connect to NE's that are being polled by the same CPMC as the local NE to which you are directly connected – via the PNMT cable.




PNMT Main window (1+1 configuration)

2.10 License

To protect PNMT functions, the PNMT application includes license files.

To display the current license status,

1. Click **Help → License...** in the main window.



When changing the license file, click **[Import]**.

2.11 Overall Tab

This tab is displayed at startup. The overall tab provides an overall snapshot of the most significant monitored items of the NE.

TX Attenuation	0dB
TX Frequency	13199.000MHz
RX Frequency	12933.000MHz
Bit Rate	4x2MB
MAINT	OFF
Frame ID	0

1+0 Overall window

TX Attenuation	0dB
TX Frequency	13199.000MHz
RX Frequency	12933.000MHz
Bit Rate	4x2MB
MAINT	OFF
Selected TX	No.1
Selected RX	No.1
Frame ID	0

1+1 Overall window

The following items are displayed with this tab:


- TX Attenuation – the current value (in dB) of the internal attenuation set in the ODU.
- TX Frequency – the currently used transmission frequency.
- RX Frequency – the currently used reception frequency.
- Bit Rate – the current bit rate setting of the IDU.
- MAINT – the current **Maintenance** status.
- Frame ID – the set frame ID of the NE.
- Selected TX (for 1+1 system only) – shows the currently used signal transmission system
- Selected RX (for 1+1 system only) – shows the currently used for signal reception.

2.12 ODU Tab


This function is used to display the values and status of the monitored items of the ODU.

To view the alarm and status display of the ODU:

1. Click the **ODU** tab in PNMT main window of the target NE.



1+0 ODU window



ODU window (1+1 configuration)

Monitored Items

TX PORTION

Alarm

IF INPUT - Monitor IF signal Input. Item/Status field is shown with transparent letters and gray background in case of CPU Alarm or IDU-ODU LINK Alarm.

TX POWER - Monitor TX Power. Item/Status field is shown with transparent letters and gray background in case CPU Alarm or IDU-ODU LINK Alarm.

TX APC - Monitors the Automatic Phase Control unit. Item/Status field is shown with transparent letters and gray background in case of CPU Alarm or IDU-ODU LINK Alarm.

Status/Monitoring

TX Attenuation - the current value (in dB) of the internal attenuation set in ODU. Item and status fields are shown and item field uses black fonts and status indicates no information in case of TX Power Control is ATPC or CPU Alarm or IDU-ODU LINK Alarm.

TX Power – the transmitting power of the ODU in volt and dBm. Item and status fields are shown and item field uses black fonts and status indicates no information in case of CPU Alarm or IDU-ODU LINK Alarm.

RX PORTION

Alarm

RX LEVEL - Monitor RX Level. Item/Status field is shown with transparent letters and gray background in case of CPU Alarm or IDU-ODU LINK Alarm.

RX APC - Monitors the Automatic Phase Control unit. Item/Status field is shown with transparent letters and gray background in case of CPU Alarm or IDU-ODU LINK Alarm.

Monitoring

RX Level - Display RX Level value in volt and dBm. Item and status field are shown and item field uses black fonts and status indicates no information in case of CPU Alarm or IDU-ODU LINK Alarm.

COMMON PORTION

Alarm

IDU-ODU LINK – the fail of connection between IDU and ODU. Item/Status field is shown with transparent letters and gray background in case CPU Alarm of CPU Alarm.

Monitoring

Power Supply: Display PS value (V). Item and status fields are shown and item field uses black fonts and status indicates no information in case of CPU Alarm.

2.13 IDU Tab


2.13.1 IDU Tab

To view the alarm and status of the IDU:

1. Select the **IDU** tab in the **PNMT** main window for the target NE.

TX		RX				COMMON			
Alarm		Alarm		Alarm		Alarm		Alarm	
MOD		DEM		HIGH BER		BER ALARM			
TX DPU		LOW BER							
MUX ALARMS-1		MUX ALARM-2		MUX ALARM-3		MUX ALARM-4			
INPUT	BP OUTPUT	AIS SEND	AIS RCVD	ALARM INHIBIT					
WS	Normal	Normal	Normal	Received					OFF
CH1	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH2	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH3	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH4	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH5	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH6	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH7	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH8	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH9	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH10	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH11	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH12	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH13	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH14	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH15	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF
CH16	Normal	Normal	Normal	Received	OFF	OFF	OFF	OFF	OFF

IDU window (1+0 configuration)



IDU window (1+1 configuration)

Monitored Items

Following items are monitored.

TX PORTION**Alarm**

MOD: Monitor Modulator portion.
Item/Status area is shown with transparency letters transparent letters and gray background in case of CPU Alarm.
TX DPU : Item/Status area is shown with transparency letters transparent letters and gray background in case of CPU Alarm.
MUX ALARM : Item/Status area is shown with transparency letters transparent letters and gray background in case of CPU Alarm.
Alarm.

RX PORTION**Alarm**

DEM : Monitor Demodulator. Item/Status area is shown with transparency letters and gray background in case of CPU Alarm.
LOW BER: Item/Status area is shown with transparency letters and gray background in case of CPU Alarm.
HIGH BER: Item/Status area is shown with transparency letters and gray background in case of CPU Alarm.
BER ALARM: Item/Status area is shown with transparency letters and gray background in case of CPU Alarm.
FRAME ASYNC: Item/Status area is shown with transparency letters and gray background in case of CPU Alarm.

COMMON PORTION**Alarm**

IDU-ODU LINK: IDU-ODU LINK:
Item/Status area is shown with transparency letters and gray background in case of CPU Alarm.
TX CLK LOSS
RX CLK LOSS

WS Interface**Alarm**

INPUT: Item and status areas are not shown in case WS Interface is not mounted.
BP OUTPUT: Item and status areas are not shown in case WS Interface is not mounted.

Status

AIS SEND: Item and status areas are not shown in case WS Interface is not mounted.
AIS RCVD: Item and status areas are not shown in case WS Interface is not mounted.
ALARM INHIBIT : Alarm inhibit state of the WS.

Channels (CH):**Alarm**

INPUT
BP OUTPUT


Status

AIS SEND
AIS RCVD
LB1 : Near-end Loop back status
LB2 : Custom Loop back status
ALARM INHIBIT : Alarm inhibit state of the channel.

2.13.2 Loop Back

To set the loop back:

1. Click of the target channel in IDU window
2. Select **LB1** or **LB2** Tab in the ensuing window.



3. These are available for when Usage is used on the channel. Select **ON** to activate the loop back or select **OFF** to remove the loop-back.

NOTE


Switch ON maintenance mode first before executing the loop back.

4. Click **[Execute]** to activate the operation.
5. Click **[Close]** when finished.

2.13.3 Alarm Inhibit

(a) For Traffic channel

1. Click **CH** offor the selected channel in IDU window
2. Select the **ALARM** Tab window.



3. Select **ON** to inhibit the alarm of that channel or **OFF** to activate the alarm.
4. Click **[Execute]** to activate the operation.
5. Click **[Close]** when finished.

(b) Wayside channel (option)

1. WS Alarm Inhibit setting is available when WS Interface is mounted. Click **[WS]** of in IDU window.



2. Select **ON** to inhibit the alarm offor that channel or **OFF** to activate the alarm.
3. Click **[Execute]** to activate the operation.
4. Click **[Close]** when finished.

2.14 Auxiliary I/O Tab

4-relay outputs and 6 optocoupler inputs are provided in the IDU for external control and alarms. The setting for each relay output/optocoupler input is available by clicking on the selected device in the Auxiliary I/O Monitor window.

To monitor and set the Auxiliary I/O:

1. Select the **Aux. I/O** tab in the **PNMT main** window

Alarm/Status/Control		
Input-1	Opto-1	Open
Input-2	Opto-2	Open
Input-3	Opto-3	Open
Input-4	Opto-4	Open
Input-5	Opto-5	Open
Input-6	Opto-6	Open
Output-1	Relay-1	Open
Output-2	Relay-2	Open
Output-3	Relay-3	Open
Output-4	Relay-4	Open

AUX. I/O window

Monitored Item


Following items are monitored.

2. Six (6) optocoupler inputs (Input-1 - Input-6)
3. Four (4) relay outputs (Output-1 - Output-4)

2.14.1 Optocoupler Input Setting


To set the Optocoupler input:

1. Click on the selected **[Input-n]** button in **Aux. I/O** tab.



2. Enter the name of designation of the **Input** in the **Name** field. A maximum of 32 characters can be used
3. Select the Alarm condition of the **Input**. You can select the events for which when the target Input will send the alarm signals to the PNMS/PNMT. Also you can preset the input to just send transmit the Status of for the input instead of an alarm signal.
4. Click **[Execute]** to activate the selected state of the device.
5. Click **[Close]** when finished.

2.14.2 Relay Output Setting



To set the relay output:

1. Click **[Output-n]** in Aux. I/O window.
2. Enter the desired designation (name) on in the **Name** field. A maximum of 32 characters can be used.
3. To open or close the relays click on the **Event ON**; or to close them click **Event OFF**. button respectively.
4. Enter the desired strings for the open and close states of the Relay in the appropriate **Event ON** and **Event OFF** fields. A maximum of 32 characters can be used
5. Click **[Execute]** to carry out the command.
6. Click **[Close]** when finished.


2.15 PM Card Monitor

2.15.1 PM Card Monitor

1. Select the **PMC** tab in **PNMT main** window of the target NE.

The following items can be monitored and controlled in the PMC tab:

- PMC-ALM CONT LINK: The alarm indicates the communication state between PM CARD and IDU.
- Date/Time
- PMC Reset
- Download Configuration File
- Download Program File
- Upload Configuration File




2.15.2 Setting the Date/Time

The Date and Time stored in the PM card can be displayed and adjusted using this function.

To set the Date/Time:

1. Click **[Date/Time]** in the **PMC** tab.



NOTE

To set the value of the Date and Time field to the same value as that of the PNMT computer, check on the Display PC Time box.

1-1) To check the Date and Time on the PM Card:

- 1) Select **Get Date/Time** in the Date/Time window.
- 2) Click **[Execute]**.
- 3) The current date and time in the PMC will be displayed in the **Date** and **Time** field.

1-2) To set the Date and Time on the PM Card:

- 1) Select **Set Date/Time** in the Date/Time window.
- 2) Click **[Execute]**.
- 3) Click **[Close]** when finished.

2.15.3 PM Card Reset


The PM card can be reset using this function

NOTE

Resetting the PMC will not affect the traffic. The connection to the selected Pasolink will be disrupted for a few minutes but will automatically be restored.

To reset the PM Card:

1. Click **[PMC Reset]** in PMC tab.
2. You can select the **with ROM (PMC Program) Switching** option if you want to switch to a newly downloaded PMC Program file.
3. Click **[Execute]** to continue the PMC reset operation.



NOTE

Switch ON maintenance mode first before executing PMC Reset.


4. Click **[Close]** when finished.

2.15.4 Downloading the Configuration Files to the PMC

This function is used to download configuration files from the PNMT to the PM card. The configuration file - system.cfg, contains the IP addresses of the PM card as well as the IP address of the opposite station. The network.cfg file contains the information about the Pasolink network where the PM card is located.

To download new configuration file to the PM card:

1. Click **[Configuration File]** in PMC tab's **Download (PC>>PMC)** section.



2. Select the type of file to be downloaded in the **Type** list.
3. Enter the location of the configuration file in the **File** field, or click **[Browse]** to locate the file on the local hard disk or diskette.

WARNING!!!

Make sure that the correct configuration file is downloaded to the correct PM card. Incorrect configuration files will lead to can cause PM card or network failure.

4. Click [Execute] to start the operation.

NOTE


**Switch ON maintenance mode first, before then
executing the Download Configuration File.**

5. A message window indicating the status of the operation will appear. It will close automatically once the operation is finished.

WARNING!!!

Make sure that you have successfully downloaded the configuration file before attempting an Update. Otherwise the PM Card will switch to an empty ROM that may cause PM Card failure.

6. Click [Update] to activate the new configuration file(s).
7. Select the appropriate box for the type of configuration file that will be updated. One or more configuration file can be updated by checking the box opposite to the configuration file name. Click [Execute] to start the operation. The "with ROM (PMC Program) Switching" box is for switching to the ROM with the new PMC Program and has the same function that was previously discussed in section.



NOTE

When updating system.cfg file, PMC to PMC communication will be disrupted when the PMC re-initializes to the new system configuration. This WILL NOT affect the radio link. During this time PNMT connection to the PASOLINK will be disrupted, but it will automatically be restored after the PMC resets.

NOTE

Updating the PMC will not affect the traffic. The connection to the selected Pasolink will be disrupted for a few minutes, but it will automatically be restored.-


8. Click [Close] when done.

2.15.5 Downloading a New Program File for the PMC

This function is used to update the application program on the PM card. This operation affects only the PMC to PMC communication but not the wireless link, and will not disrupt communications.

To download the program file to PM Card:

1. Click [Program File] in PMC tab's Download (PC>>PMC) section.



2. Enter the appropriate location of the program file (*.pof) in the **File** field. Otherwise, click **[Browse]** to locate the file.

WARNING!!!


Make sure that the correct program file is downloaded to the PM card. Incorrect program files may cause PM card failure.

3. Click **[Execute]** to start the operation.

NOTE

First switch maintenance mode ON before executing Download Program File.


4. A message window will appear displaying the status of the operation. The message window will close automatically once the download is completed.



NOTE

This operation may take several minutes depending on the program file size.

5. Click [PMC Reset] to switch to the new program file.



6. Check the **with ROM (PMC Program) Switching** box.
7. Click [Execute] to complete the switch to the new program file.

NOTE

**The connection from PNMT to the selected PASOLINK
will be disrupted for a few minutes but will be
automatically restored.**

8. Click [Close] when done.

2.15.6 Uploading PMC Configuration File to PNMT PC

This function is used to upload the configuration file from the PM card of the selected Pasolink to the PNMT PC.

To upload configuration file from the PM card to PNMT:

1. Click [Configuration File] in PMC tab's **Upload (PMC>>PC)** section.



2. Select the type of file to be uploaded with the **Type** field.
3. Click [Execute] to start the operation.
4. Enter the desired file name for the uploaded file. And select and the directory where the uploaded file will be saved.
5. A message window indicating the status of the operation will appear. It will close automatically once the operation is completed.
6. After the upload is finished click [Close].
7. Verify that the file was uploaded on the specified directory.

2.16 Maintenance

There are ten maintenance control items that can be executed in the maintenance menu. The function of each control is as follows.

MAINT: To switch Maintenance mode to ON

TX Mute: To turn off TX power

CW (MOD Carrier): To turn on the Continuous Wave for measurements


BER AIS: Bit Error Rate Alarm Indication Signal

*These windows are not available when MAINT is OFF. (“Switch to Maintenance mode first” message is displayed.)

2.16.1 Maintenance Menu

To go to maintenance window:

1. Select **Configuration → Maintenance** in the NE-specific menu bar, or click **MAINT** button in the **Block Diagram**. The contents of the Maintenance window will depend on type of IDU used. The proceeding pictures show the possible contents of the Maintenance window according to the IDU type.




MAINT	OFF
TX Mute	OFF
CW(MOD Carrier)	OFF
BER AIS	ON
TX Switch	Auto
RX Switch	Auto

Maintenance window (1+1 configuration)

2.16.2 Selecting Maintenance Mode

To switch the Pasolink to maintenance mode:

1. Click [MAINT] in **Maintenance** window. When the Maintenance mode is ON, the status column appears in yellow.
2. Select **ON/OFF** depending on desired state.
3. Click **[Execute]** to carry out the command.
4. Click **[Close]** when finished.



NOTE

When the Maintenance mode is to be turned OFF, make sure that all items/functions controlled in maintenance mode are turned OFF first. Otherwise, it is not possible to turn OFF the maintenance mode..

2.16.3 Selecting TX Mute Status

TX power of the ODU is switched off when TX Mute is **ON**. This should be **OFF** in normal operation.

To change the TX Mute status:

1. TX Mute function is available for the NE with which the connection cable is connected directly from PNMT. The control screen does not open and it is not possible to control the NE that are wireless opposite counterparts or connected remotely by search. Click **[TX Mute]** in **Maintenance** window



NOTE

Switch ON maintenance mode first before executing TX Mute.

2. Select **ON/OFF** depending on the desired state. When TX Mute status is ON, the status column appears in yellow.

3. Click [Execute] to carry out the command.

CAUTION

A message will appear, indicating that when TX mute is ON, the wireless link connection will be affected. The connection to the opposite Pasolink will be disrupted for a few minutes.

4. Click [Close] when finished.

2.16.4 Selecting Carrier Wave Status

When measuring frequencies, the CW should be turned ON to have an unmodulated signal. During normal operation this status should be OFF.

To change the CW (MOD Carrier) status:

1. CW function is available for the NE with which the connection cable is plugged directly into the PNMT. The control screen does not open and it is not possible to control for the NE which is at wireless opposite or connected remotely by search. Click [CW (MOD Carrier)] in Maintenance window



NOTE

Switch ON maintenance mode first before executing CW.

2. Select ON/OFF button depending on desired state. When CW status is ON, the status column appears in yellow.
3. Click [Execute] to carry out command.

CAUTION

A message will appear, indicating that when CW is ON, the wireless link connection will be affected. The connection to the opposite Pasolink will be disrupted for a few minutes.

4. Click [Close] when finished.

2.16.5 Selecting BER AIS

To change the CW (MOD Carrier) status:

1. Click [BER AIS] in Maintenance window



NOTE


Switch ON maintenance mode first before executing BER AIS.

2. Select **ON/OFF** depending on desired state. When BER ALM >> AIS status is OFF, the status column appears in yellow.
3. Click **[Execute]** to carry out command.
4. Click **[Close]** when finished.

2.16.6 Switchover (For 1+1 system only)

To switchover to the other system in 1+1 configuration:

1. Click **[Switchover]** in Maintenance window



NOTE


First Switch ON maintenance mode before executing switchover.

2. Select the whether to manually switchover to No. 1 or No.2 or allow the Pasolink to Auto switchover. The switchover is normally set on Auto.
3. Click **[Execute]** to apply the new setting.
4. Click **[Close]** when finished.

2.16.7 TX Switch (For 1+1 system only)

To switchover to the other system in 1+1 configuration:

1. TX Switch function is only available for 1+1 system. There is none for 1+0. Click **[TX Switch]** in Maintenance window



NOTE


Switch ON maintenance mode first before executing TX Switch.

2. Select whether to manually transmit (TX) to No. 1 or No.2 or allow the PASOLINK to Auto TX Switch. The TX Switch is normally set on Auto. When TX Switch status is No.1 or No.2 except Auto, the status column appears in yellow.
3. Click **[Execute]** to apply the new setting.
4. Click **[Close]** when finished.

2.16.8 RX Switch (For 1+1 system only)

To switchover to the other system in 1+1 configuration:

1. RX Switch function is only available when 1+1 system. There is no area in case 1+0. Click [RX Switch] in Maintenance window



NOTE

**Switch ON maintenance mode first
before executing RX Switch.**

2. Select the whether to manually RX to No. 1 or No.2 or allow the PASOLINK to Auto RX Switch. The RX Switch is normally set on Auto. When TX Switch status is No.1 or No.2 except Auto, the status column appears in yellow.
3. Click [Execute] to apply the new setting.
4. Click [Close] when finished.


2.17 Equipment Setup

Main signal, Wayside signal, Service signal, ODU and PM card portion can be monitored and controlled in this window.

2.17.1 Equipment Configuration Monitor

To open the Equipment Configuration Monitor:

1. Select **Configuration** → **Equipment Setup** in the NE-specific menu bar.



- ❖ ODU Capacity shown in this window refers to the transmission capacity of the equipment in the inventory.
- ❖ IDU Bit Rate is the actual operating bit rate used by the system. This is always within the transmission capacity of the ODU in the inventory.
- ❖ When ODU capacity indicates 34 MB, IDU bit rate is set to 8x2 or 16x2 Mbps, it means that two or four 2 MB Interface cards are used.
- ❖ ODU capacity indicates 8 MB if IDU bit rate is set to 2x2 or 4x2 Mbps, it means that only one 2 MB Interface card is used.

Equipment Setup window

2.17.2 Setting the Frequency Plan

To setup the frequency plan:

1. Click **[Frequency Plan]** in the **Equipment Setup** window.
2. On the **Frequency Plan** window, only the **TX/RX CH** is configurable. The rest of the items are grayed-out in the screen and are automatically set according to the allocated channel in **TX/RX CH**.

NOTE: For ODU Version 2, the RF Band, High/Low Band, shift Frequency, CH Separation, Sub-Band and TX/RX CH are manually configurable. For ODU Version 3, these parameter columns are written by light-gray font and covered with background color.

3. Click **[Execute]** to activate the new set of values.



CAUTION

The message that changing TX channel will effect the radio link connection will appear.

4. Click **[Close]** when finished.

2.17.3 Setting the TX Attenuation

To set the TX attenuation:

1. Click **[TX Attenuation]** in the **Equipment Setup** window.
2. Select the value of the attenuation by pulling down on the menu. The attenuation is set in dB. The control range depends on ODU type.
3. Click on **[Execute]** button to activate the new TX attenuation on the ODU.
4. Click on **[Close]** button when finished.




2.17.4 Bit Rate Setting

NOTE:

- Bit Rate can be selected only for **Bit Rate Free**-type Pasolink.
- The Bit-Rate set in this window is the operating bit-rate of the System. The inventory operating mode, or the ODU Capacity is shown in the ODU block in the Equipment setup window. The total operating bit-rate is always within the ODU transmission capacity.
- Changing the Bit Rate of opposite radio may have an effect on the Custom Loop back (LB2) status of local radio. In case this occurs, cancel (turn off) the state of LB2 manually. The procedure for LB2 is shown in section 2.12.2.

To set the Bit Rate value:

1. Click [Bit Rate] in Equipment Configuration window.



2. Select the bit rate value by clicking on the appropriate bit rate button displayed in the **Bit Rate** window.

NOTE

Some of the bit rate button may not be selectable - depending on to the type of IDU used.

3. Click [Execute] to set the bit rate to the new value set.

CAUTION


The message that changing Bit Rate will effect the radio link connection will appear.

4. Click [Close] when finished.

2.17.5 Setting the Frame ID

To set the Frame ID:

1. Click [Frame ID] in the **Equipment Setup** window.
2. Select the desired value of the Frame ID from the pull-down menu. The Frame ID can be set from 0 to 7. Make sure that both NE's in the hop are using the same Frame ID.
3. Click [Execute] to activate the new Frame ID.
4. Click [Close] when finished.



2.17.6 Setting the BER Threshold

To set the BER Threshold:


1. Click [BER Threshold] in the Equipment Configuration window.
2. Select the desired value of the BER Threshold.
3. Click [Execute] to activate the new setting.
4. Click [Close] when finished.



2.17.7 Setting the AIS SEND

To set the AIS SEND:


1. Click [AIS SEND] in the **Equipment Configuration** window.
2. Select whether you want the AIS SEND to send an Alarm to the upper system when activated or just Status – just as an entry in the Event Log.
3. Click [**Execute**] to activate the new setting.
4. Click [**Close**] when finished.



2.17.8 Setting the AIS RCVD

To set the AIS RCVD:

1. Click [AIS RCVD] in the **Equipment Configuration** window.
2. Select whether you want the AIS RCVD to send an Alarm to the upper system when activated or just Status – just as an entry in the Event Log.
3. Click [**Execute**] to activate the new setting.
4. Click [**Close**] when finished.



2.17.9 Setting the Service Channels (SC4/SC5)

To set the Service Channels –SC4 and SC5:

1. Click either [SC4] or [SC5].




2. Select desired speed and interface to be associated with the service channel.
3. Click [**Execute**] to activate the new setting
4. Click [**Close**] when finished.

2.17.10 Editing the NE Name

To edit the NE name:


1. Click [NE Name] in **Equipment Setup** window.
2. Enter new Pasolink name in the **NE Name** dialog box. A maximum of 32 characters can be used.
3. Click [**Execute**] to change to new name.
4. Click [**Close**] when finished.



2.17.11 Editing the Note for NE

To put an optional description on the current Pasolink:

1. Click **[Note]** in **Equipment Setup** window.
2. Enter the optional description for the specific Pasolink in the **Note** dialog box. A maximum of 100 characters can be used in this field
3. Click **[Execute]** when finished.
4. Click **[Close]** when finished.



2.18 Link Performance Monitor

The following performance items can be monitored according to G.826 recommendation:


- ES:** Errorred seconds
- SES:** Severely errored second
- UAS:** Unavailable Seconds
- BBER:** Background Block Error

This window displays each performance items value in two kinds of measurement periods, a 15-minute interval (15 min) and a 24-hour interval (Day). The current (%) value of 15 min and Day in the left table means the value of counts of ES, SES, UAS and BBER every 15 minutes and per day (24 hours) as a percentage respectively. Each value is calculated based on the following method. The background color for each value is the result of the threshold value setting. That is, if a measurement data value exceeds an alarm occurrence (occur) level, the background color will turn pink, and will not revert to white until a measurement data value is less than the alarm resolution (*recover*) level. The threshold values can be set in the Threshold window. Moreover, all data can be reset with the **[All Data Reset]** button. A detailed daily performance data can be seen by clicking **[Detail]**.

2.18.1 Viewing Summary Link Performance Monitor

To view Summary Link Performance Monitor:

1. Click **Link Performance Monitor** in the **NE-specific** menu bar of the target Pasolink – the Pasolink that you intend to monitor.



Summary Link Performance Monitor window

Current (%)

ES, SES, UAS (15 min)

The number (A) of counts for 15 minutes is divided by 900 seconds, which is multiplied by 100 and the result is displayed as a percentage.

$$Value = \frac{A}{900} \times 100$$

BBE (15 min)

The blocks number times 900 seconds, which is multiplied with 100 divide the number (A) of counts for 15 minutes and the result is displayed as a percentage. The value of blocks depends on the bit rate. (Refers to the following table of the relation of blocks value and bit rate).

$$Value = \frac{A}{900 \times blocks} \times 100$$

ES, SES, UAS (Day)

The number (A) of counts through fixed 15 minutes period from 00:00 to 23:45 is divided by total number of seconds (B) where B is 900 seconds * number of 15 minutes blocks. The value is multiplied with 100 and the result is displayed as a percentage.

$$Value = \frac{A}{B} \times 100$$

Note) the maximum B value is 86400(=900*96) seconds.

BBE (Day)

The number (A) of counts through fixed 15 minutes period from 00:00 to 23:45 is divided by total number of seconds (B) times blocks value where B is 900 seconds * number of 15 minutes blocks. The value is multiplied with 100 and the result is displayed as a percentage. The value of blocks depends on the bit rate. Refers to the following table of the relation of blocks value and bit rate.

$$Value = \frac{A}{B \times blocks} \times 100$$

Note) the maximum B value is 86400(=900*96) seconds.

The current status color

If the threshold alarm occurs in a certain measurement period, the background color of the value of corresponding performance item changes from white to pink and the background color changes from pink to white only after the value of performance item does not exceed the threshold recover level once during the next measurement period,

History 15 min status

The status of each performance items on 15 min of History in table means the existence of threshold alarm occurrence. The “Alarm” string in field indicates an occurrence of the performance items exceeding the threshold alarm occur level at least in the 15-minute interval data for the past seven days. In order to change from “Alarm” to “Normal”, it is required for the past seven days for each 15-minute interval data not to exceed a threshold alarm resolution (*recover*) level.

History Day status

The status of each performance items on Day of History in table means the existence of threshold alarm occurrence. The “Alarm” string in field indicates an occurrence of the performance items exceeding the threshold alarm occur level at least in the 24-hour interval data for the past seven days. In order to change from “Alarm” to “Normal”, it is required for the past seven days for each 24-hour interval data not to exceed the threshold alarm resolution (*recover*) level.


	Bit Rate	Blocks per second(blocks)
1	2*2 MB	341
2	4*2 MB	1338
3	8*2 MB	1338
4	16*2 MB	1338
5	1*8 MB	559
6	1*34 MB	2166
7	4*1.5 MB	603
8	8*1.5 MB	603
9	1*45 MB	2427
10	16*1.5 MB	603

The relation of blocks value and bit rate

2.18.2 Threshold Setting

To set the threshold values:

1. Click [Threshold (%)] in the **Summary Link Performance Monitor** window



2. Select the performance item that is to be configured on the table shown above. The G.826 measure becomes available for setting when selected. The arrow buttons on the left-hand side of the field indicates this.
3. Set the value when the alarm **Occur** and when the alarm **Recover** in the appropriate field. The measure will issue an alarm status when it reaches the alarm occur value or issue an alarm clear status when it reaches the recover value set in the threshold table.
4. Click **[Execute]** to activate the new settings.
5. Click **[Close]** when finished.

The threshold value used in this table is in percentage. The “alarm recover” level must have value smaller than the “alarm occur” level. In case the threshold value you want to use is in count (as shown in the below table), please convert it into percentage first according to the explanation in the preceding chapter.

	Performance Item	Threshold (count) (A)	Expression	Threshold (%) (B)
15min	ES,SES,UAS	90	A/900*100=B	10.00
	BEE(BitRate=2*2MB)	3069	A/(900*blocks)*100 (Blocks=341)	10.00
1Day	ES,SES,UAS	8640	A/86400*100=B	10.00
	BEE (BitRate=2*2MB)	2946240	A/(86400*blocks)*100 (Blocks=341)	10.00


Threshold value Conversion

2.18.3 Link Performance Monitor (Daily Data) window.

This window contains the 24-hour performance data of the current 8 days.

To view the Link Performance Monitor (Daily Data) window:

1. Click [Detail] in Link Performance Monitor window.



The screenshot shows a window titled "Link Performance Monitor [Daily data] - No.001". The window has a menu bar with "File" and "View". Below the menu is a toolbar with three icons: a floppy disk (Save), a monitor (View), and a percentage sign (%). The main area is a table with the following data:

Date	ES	SES	UAS	BBE
05/17/2002				
05/16/2002	86	0	0	0
05/15/2002	0	0	0	0
05/14/2002	0	0	0	0
05/13/2002	0	0	0	0
05/12/2002	0	0	0	0
05/11/2002	0	0	0	115603
05/10/2002	0	0	0	0

At the bottom of the window, there are status indicators: "Ready", "File Size: 536 Bytes", and "100%".

Link Performance Monitor (Daily Data) window

2. On this window a table presents the available data in the PMC. The table is presented as G.826 measure versus the Date. The date buttons on the right-hand side of the table is selectable. Moreover, the buttons reflect the summary alarm for that specific date.
3. Click on the date buttons to display the detailed 15-min data for that date.

2.18.4 Link Performance Monitor (15-min Data) window

To view the 15-min Data:

1. Click of the target date in Link Performance Monitor (15-min Data) window to display the detailed 15-min performance data.

Link Performance Monitor [15-min data] - No.001

Date: 05/17/2002

Date	ES	SES	UAS	BBE
00:00 - 00:15	0	0	0	0
00:15 - 00:30	0	0	0	0
00:30 - 00:45	0	0	0	0
00:45 - 01:00	0	0	0	0
01:00 - 01:15	0	0	0	0
01:15 - 01:30	0	0	0	0
01:30 - 01:45	0	0	0	0
01:45 - 02:00	0	0	0	0
02:00 - 02:15	0	0	0	0
02:15 - 02:30	0	0	0	0
02:30 - 02:45	0	0	0	0
02:45 - 03:00	0	0	0	0
03:00 - 03:15	0	0	0	0
03:15 - 03:30	0	0	0	0
03:30 - 03:45	0	0	0	0
03:45 - 04:00	0	0	0	0
04:00 - 04:15	0	0	0	0
04:15 - 04:30	0	0	0	0
04:30 - 04:45	0	0	0	0
04:45 - 05:00	0	0	0	0
05:00 - 05:15	0	0	0	0


Ready File Size: 4747 Bytes 100%

Link Performance Monitor (15-min Data) window

2. The data can be saved in text format by clicking on the save icon. Or can be refreshed by clicking on the refresh button.

2.18.5 All Data Reset

1. Click [All Data Reset] in Summary Link Performance Monitor window.



WARNING!!!

**Make sure that the current data has been saved.
This operation will delete all the performance data in the current week.**


2. Click [Execute] to reset all the data.
3. Click [Close] when finished.

2.19 NE Stored Log

The NE Stored Log window displays the date when the event or command was received, the equipment, item, and status.

2.19.1 NE Stored Log Monitor

1. Click **NE Stored Log** in **NE-specific** menu bar of the target PASOLINK – the PASOLINK that you intend to monitor.
2. A message window showing the progress of the uploading of the NE Stored Log data will appear on screen. Wait until the PNMT finishes the uploading of the data. The progress window will automatically close once the uploading is completed.
3. The **NE Stored Log View** will be displayed. The NE Stored Log is presented in a table form showing the date of the event, the item that triggered the event and the status change.



The screenshot shows a window titled "NE Stored Log - No.001". The window has a menu bar with "File" and a toolbar with icons for "Home", "Print", and "Save". The main area is a table with the following columns: Date/Time, Network Element, Item, Status, and Type. The table contains 10 rows of log entries. The last row is highlighted in yellow. At the bottom of the window, there is a status bar with "Ready", "Total Events: 298", "File Size: 30098 Bytes", and a zoom level of "100%".

Date/Time	Network Element	Item	Status	Type
05/17/2001 18:21:42	No.001	PNMT(LOCAL) LINK	CONNECT	SYSTEM
05/17/2001 18:28:03	No.001	PNMT(LOCAL) LINK	DISCONNECT	SYSTEM
05/17/2001 18:31:48	No.001	PNMT(LOCAL) LINK	CONNECT	SYSTEM
05/17/2001 18:32:41	No.001	INPUT-6 SEVERITY	CHANGED	CONFIG
05/17/2001 18:32:48	No.001	INPUT-6 SEVERITY	CHANGED	CONFIG
05/17/2001 18:32:53	No.001	INPUT-6 CONDITION	STATUS	CONFIG
05/17/2001 18:32:53	No.001	INPUT-6 SEVERITY	CHANGED	CONFIG
05/17/2001 18:32:56	No.001	INPUT-6 CONDITION	ALARM WHEN EVENT ON	CONFIG
05/17/2001 18:32:59	No.001	INPUT-6 SEVERITY	CHANGED	CONFIG
05/17/2001 18:33:02	No.001	INPUT-6 SEVERITY	CHANGED	CONFIG
05/17/2001 18:34:39	No.001	PNMT(LOCAL) LINK	DISCONNECT	SYSTEM

2.20 Version Tab

The inventory information of the PM card, ODU and IDU can be viewed using this function.

2.20.1 Version Monitor

To display version of ODU, IDU and PMC:

1. Select the **Version tab** in **PNMT** main window.
2. The version tab shows the Date of Manufacture, Software Version, Serial No. and Code No. of the ODU, IDU and PMC. Note that only ODU V3 supports this function.

ODU	
Date of Manufacture	1900/0
IDU	
Date of Manufacture	1900/0
Software Version	0.0
PMC	
Code No.	G5440A
Serial No.	1234
Date of Manufacture	2001/7
Software Version	2.15

Version window for (1+0)

ODU	
No.1	No.2
Date of Manufacture	1900/0
IDU	
No.1	No.2
Date of Manufacture	1900/0
Software Version	0.0
	Switch
	1900/0
	0.0
PMC	
Code No.	G5440A
Serial No.	1234
Date of Manufacture	2001/7
Software Version	2.15

Version window for (1+1)

2.21 License import

2.21.1 License import

To update the license file:


1. Go to **Help → License** in menu bar on PNMT main window.




2. Import License Wizard will appear on screen. Click [Next] to continue.




3. Click [...] to locate the new license key file.




4. Indicate a License key file (i.e. License.key) that will be associated to PNMT. Select a License key file and click [Open] to continue.




5. After verifying the path to License key file is correct, click [Next] to proceed.



6. The progress of the checking of the license file will be displayed. If no error is encountered during checking of the license file, click [Next] when the button becomes available.



7. Verify the contents of license you are applying for.



8. Click [Finish] in ensuing window to complete the license application.

